

## TECHNICAL DATA

# Fluke 9040 Phase Rotation Indicator



## Key features

- 3 phase indication
- Indication of phase rotation
- Clear LCD display
- No battery required

## Product overview: Fluke 9040 Phase Rotation Indicator

### Phase rotation indicator with high voltage capability for industrial applications

The Fluke 9040 is effective for measuring phase rotation in all areas where three phase supplies are used to feed motors, drives and electrical systems. The Fluke 9040 is a rotary field indicator and can provide clear indication of the 3 phase via an LCD display and the phase rotation direction to determine correct connections. It allows rapid determination of phase sequence and has a voltage (up to 700 V) and frequency range suitable for commercial and industrial applications. The included test probes have a variable clamping range for safe contact, also in industrial sockets.

## Specifications: Fluke 9040 Phase Rotation Indicator

### Technical Specifications

|                                              |                      |
|----------------------------------------------|----------------------|
| Voltage Range                                | 40-700 V             |
| Frequency Range                              | 15-400 Hz            |
| Operating Timer                              | Continuous           |
| <b>Environmental Specifications</b>          |                      |
| Operating Temperature                        | 0°C to 40°C          |
| Dust/Water Resistance                        | IP 40                |
| <b>Safety Specifications</b>                 |                      |
| Electrical Safety                            | EN 61010,            |
|                                              | EN 61557-7           |
| Overvoltage category                         | CAT III, 600 V       |
|                                              | CAT IV, 300V         |
| <b>Mechanical and General Specifications</b> |                      |
| Size                                         | 124 x 61 x 27 mm     |
| Weight                                       | 200 g                |
| Power supply                                 | From unit under test |
| Warranty                                     | 2 years              |

## Ordering information



### **Fluke 9040**

Fluke 9040 Phase Rotation Indicator

---

Includes:

- 3 self-retaining test probes (black)
  - alligator clip
  - user manual
-

**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**For more information call:**  
In the U.S.A. (800) 443-5853  
In Canada (800) 36-FLUKE  
From other countries +1 (425) 446-5500  
[www.fluke.com](http://www.fluke.com)

©2025 Fluke Corporation.  
Specifications subject to change without notice.  
05/2025

**Modification of this document is not permitted  
without written permission from Fluke  
Corporation.**