

TECHNICAL DATA

Fluke 700PRV-1 Pressure Relief Valve Kit



Key features

- Adjustable from 725 to 5800 PSI (50 to 200 bar)
- Preset at 2,900 psi/200 bar
- Repeatability to 10% of nominal setting
- Installs directly into the 700HTP-1 pump

Product overview: Fluke 700PRV-1 Pressure Relief Valve Kit

The Fluke 700PRV-1 consists of a relief valve settable from 725 to 5800 PSI (50 to 200 bar) to be used with the 700HTP-1 Hydraulic Test Pump. The 1/8" NPT male thread fits directly into the Fluke 700HTP-1 pressure pump.

To be used with the 700HTP-1 Hydraulic Test Pump. The 700PRV uses a multi-turn adjustment screw to set preload on internal disc springs. This relief valve will protect the most commonly used Fluke pressure modules and pressure instruments from damage due to accidental over-pressurization.

Specifications: Fluke 700PRV-1 Pressure Relief Valve Kit

Ordering information



Fluke 700PRV-1

Fluke 700PRV-1 Pressure Relief Valve Kit

-
- One adjustable relief valve
 - Instruction sheet
-

Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2025 Fluke Corporation.
Specifications subject to change without notice.
06/2025

**Modification of this document is not permitted
without written permission from Fluke
Corporation.**