Australia / NZ Partners | Where To Buy





# **Product Family**

# Miller Rope Grabs and Vertical Lifelines (AUS)

Rope Grabs move easily up and down vertical lifelines providing continuous fall protection. Trailing models offer complete hands-free operation. In the event of a fall, Miller rope grabs lock quickly.

Visit MillerFallProtection.com >

Honeywell MILLER®

# **Product Numbers & Ordering Information**

Product Numbers	Details
1007031	Rocker Type 1 "Automatic; Suitable rope: polyester 12mm and kermantle 11mm; Conforms to AS/NZS 1891.3 as a type 1 fall arrest device."
ALT/12	Altochute Automatic; Suitable rope: polyester 12mm; Conforms to AS/NZS 1891.3 as a type 1 fall arrest device.
ALT/16	Altochute Automatic; Suitable rope: polyester 16mm; Conforms to AS/NZS 1891.3 as a type 1 fall arrest device.
KIBLOCK	Kiblock Type 1 Manual; Suitable rope: polyester 12mm, polyester 16mm and Kermantle 11mm; Conforms to AS/NZS 1891.3 as a type 1 fall arrest device.

#### **Additional Information**

Automatic units (Altochute & Rocker) provide hand free working, for increased productivity. The altochute suits work on lines both horizontal & vertical. All units are openable, and can be attached to an

# **Overview**

#### **Key Features**

Lightweight and industry proven automatic and manual type 1 fall arrestors lock onto the rope in the event of a sustained slip or a fall, arresting the worker immediately. The automatic units follow the worker easily without assistance, along a taught rope.

#### Miller Rope Grabs and Vertical Lifelines (AUS)

#### Recommended Industries/Use

Agriculture
 Chemical
 Construction
 Food Services
 Forestry
 Manufacturing
 Mining
 Municipal Services
 Oil and Gas
 Pharmaceutical
 Steel and Metals
 Transportation
 Utilities

#### **Hazards**

Confined Space
 Fall from height

#### Regulations

• Conforms to AS/NZS 1891.3 as a type 1 fall arrestdevice.

#### **Warranty Information**

MILLER FALL PROTECTION PRODUCT TOTAL SATISFACTION ASSURANCE At Sperian Protection, we have been providing quality Miller brand fall protection equipment to millions of workers worldwide since 1945. LIMITED LIFETIME WARRANTYBACKED BY OVER 60 YEARS IN THE FALL PROTECTION BUSINESS We sincerely believe that our fall protection equipment is the best in the world. Our products endure rigorous tests to ensure that the fall protection equipment you trust is manufactured to the highest standards. Miller fall protection products are tested to withstand normal wear and tear, but are not indestructible and can be damaged by misuse. Our Limited Lifetime Warranty does not apply to normal wear and tear or abusive treatment of the product. In the unlikely event that you should discover defects in either workmanship or materials, under our Limited Lifetime Warranty, we will repair or replace the product at our expense. If a replacement is necessary and your product is no longer available, a comparable product will be substituted. Should a product issue surface, contact us at 1300 139 166 (Aust customers) or 0800 322 200 (NZ customers) Manufacturing specifications are subject to change without notice.

## **Specifications**

#### Weight

• (ALT/12) .5kg, (KIBLOCK) .69kg, (Rocker) .170kg

#### **Operating Temp**

• -30°C to +50°C

#### Material

• (Altochute & Kiblock)- Stainless Steel, (Rocker) - Anodised Aluminium

#### Rope

• (ALT/12) - 12mm polyester rope, (ALT/16), 16mm polyester rope, (KIBLOCK) 12 & 16mm polyester rope or 11mm kernmantle rope, (Rocker) 12mm polyester rope or 11mm kernmantle rope.

#### **Specification Sheets**

• For full engineering specification sheets, go to the spec sheet section under downloads and documentation

#### Literature & Documents

ALT Altochute type 1 fall arrest device AUS NZ 2016 http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection /Rope_GrabsVertical_Lifelines/4294998705/1033.aspx
KIBLOCK type 1 fall arrest device AUS NZ 2016 http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection/Rope_GrabsVertical_Lifelines/4294998709/1033.aspx
Data Sheet Rocker Rope Lock 1007031 - AUS http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection /Rope_GrabsVertical_Lifelines/15979/1033.aspx
Data Sheet Rocker Rope Lock type 1 fall arrest device 1007031 - AUS  Instruction Manual Altochute Type 1 Fall Arrestor - AUS  http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Fall_Protection
/Rope_GrabsVertical_Lifelines/15707/1033.aspx

### Miller Rope Grabs and Vertical Lifelines (AUS)

Instructions Kiblock type 1 fall arrest device - AUS http://www.honeywellsafety.com/Supplementary/Documents\_and\_Downloads/Fall\_Protection/Rope\_Grabs\_\_\_Vertical\_Lifelines/15708/1033.aspx

Kiblock type 1 fall arrest device instructions

Instructions Rocker type 1 fall arrest device - AUS http://www.honeywellsafety.com/Supplementary/Documents\_and\_Downloads/Fall\_Protection/Rope\_Grabs\_\_\_Vertical\_Lifelines/15709/1033.aspx

Rocker type 1 fall arrest device instructions

Miller Industry Fall Protection Guide Poster - AUS http://www.honeywellsafety.com/Supplementary/Documents\_and\_Downloads/Fall\_Protection/24943 /1033.aspx

Industry Fall Protection Guide Post 13 Sperian Protection Australia Pty Ltd 3 Walker St, Braeside, Victoria 3195 Australia Tel: 1300 139 166 Fax: 1300 362 491 New Zealand Tel: 0800 322 200 www.sperianprotection.com.au POLYESTER CONSTRUCTION HARNESS WEBBING LANYARD ADJUSTABLE LANYARD MILLER ANCHOR GRIPS™ TIE-OFF ADAPTOR

# **Training & Proper Use**

Please refer to product instruction sheets included with the products prior to use.

#### **Additional Information**

marketing.australia@sperianprotection.com or ph: 1300 139 166

# **Technical Support**

1300 139 166 (Aust) or 0800 322 200 (NZ)

© Honeywell International Inc.