

TECHNICAL DATA

Fluke LVD2 Non-Contact Voltage Tester



Key features

- Non-contact AC voltage tester and LED flashlight
- Detects from 90 to 600 V AC
- Features dual-sensitivity for two levels of detection
- Indicates proximity to AC voltage source with blue light
- Indicates you're at the source with red light
- Ultra-bright white LED light with 100,000-hour bulb life
- Safety rated to CAT IV 600 V
- Operating temperature 0°C to 50°C
- AAA battery included

Product overview: Fluke LVD2 Non-Contact Voltage Tester

Fluke LVD2 Volt Light detects voltage without contact

LVD2 volt light, offered by Fluke combines a non-contact AC voltage detector and LED flashlight into one easy to use pen-style design. It features dual sensitivity detection, turning blue from 1" to 5" (2.54 cm to 12.7 cm) from the source and red when at the source. The LVD2 is a CAT IV 600 V rated and is suitable for commercial and industrial applications.

Ordering information



Fluke LVD2



Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2025 Fluke Corporation.
Specifications subject to change without notice.
05/2025

**Modification of this document is not permitted
without written permission from Fluke
Corporation.**