

Product Family

5000 Series Cup Shape Respirator (AS/NZS)

Premium cup shape respirators featuring a Willtech boomerang seal and colour-coded nose bridge. The 5000 series disposable respirators offer P1 & P2 protection.

Honeywell

Product Numbers & Ordering Information Product Numbers Details 1007691 5185 P1 cup shape respirator, unvalved P1 cup shape disposable respirator, unvalved with yellow nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134 1007693 5110 P1 cup shape respirator, unvalved P1 premium cup shape disposable respirator, unvalved with yellow nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134 5111 P1 cup shape respirator, valved 1007696 P1 premium cup shape disposable respirator, valved with yellow nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134 1007705 5140 P1 cup shape respirator, unvalved P1 premium cup shape disposable nuisance odour respirator, unvalved with brown nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134 1007708 5141 P1 cup shape respirator, valved P1 premium cup shape disposable nuisance odour respirator, valved with brown nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134 1007699 5210 P2 cup shape respirator, unvalved P2 premium cup shape disposable respirator, unvalved, with green nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134 1007702 5211 P2 cup shape respirator, valved P2 premium cup shape disposable respirator, valved, with green nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134

5000 Series Cup Shape Respirator (AS NZS)



1007711

5251 P2 cup shape respirator, valved

P2 premium cup shape disposable nuisance odour respirator, valved, with brown nose bridge. Willtech® boomerang seal. 1 box of 5. Certified to AS/NZS 1716:2012 Lic 1134



1007714

5261 P2 cup shape respirator, valved

P2 premium cup shape disposable nuisance level acid gas respirator, valved, with blue nose bridge. Willtech® boomerang seal. 1 box of 20. Certified to AS/NZS 1716:2012 Lic 1134

Additional Information

Available in P1 - For use against mechanically generated particulates and P2 - for use against mechanically and thermally generated particulates. Also available with the option of organic vapour odour relief or acid gasodour relief. Valved and unvalved versions available.

Overview

Key Features

The Honeywell 5000 series cup shape respirator, provides a high quality respiratory solution. Packed with innovative features and improved design, the new generation of no maintenance masks provides great protection. The Willtech ultra soft seal uses triple layer technology to provide the ultimate in comfort and protection. It provides the wearer with a soft textile sensation on the skin, while absorbing perspiration and ensuring an excellent seal for maximum protection. A colour coded nose bridge gives at-a-glance protection identification.

Recommended Industries/Use

- Agriculture Chemical Construction Fire Protection Forestry Government
- Manufacturing Mining Municipal Services Oil and Gas Pharmaceutical Steel and Metals
- Utilities Welding Wind Energy

Hazards

• Airborne Particulates • Contamination • Fire • Gas, Vapors, Smoke

Regulations

• Approved to AS/NZS 1716:2012 Lic 1134

Historical Brand

Willson, Sperian

Specifications

Seal

• Fitted with half-face seal (PES knit, PU foam, PU film).

Attachment Information

• Twin elastics stapled outside the filtering area.

Outer Shell

• 150g/m2 polyester non-woven.

Filter Media

Polypropylene non-woven fibers electrostatically loaded making them attractive to particles.

Nose Bridge

• Galvanised iron wire coated with polypropylene (contains no aluminium).

Weight

• 10g

Shelf Life

3 years from date of manufacture.

Literature & Documents

1007691 5185 5000 Series P1 AUSNZ

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single Use (Disposable) Respirators/4294998800/1033.aspx

1007693 5110 5000 Series P1 AUSNZ

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998801/1033.aspx

1007696 5111 5000 Series P1 with Valve AUSNZ

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998802/1033.aspx

1007699 5210 5000 Series P2 AUSNZ

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998809/1033.aspx

1007702 5211 5000 Series P2 with Valve AUSNZ

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998810/1033.aspx

1007705 5140 5000 Series P2 AUSNZ

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998811/1033.aspx

1007708 5141 5000 Series P1 with Valve AUSNZ

 $http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998812/1033.aspx$

1007711 5251 5000 Series P2 with Valve AUSNZ

http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998813/1033.aspx

1007714 5261 5000 Series P2 with Valve AUSNZ

 $http://www.honeywellsafety.com/Supplementary/Documents_and_Downloads/Respiratory_Protection/Single_Use_(Disposable)_Respirators/4294998814/1033.aspx$

Training & Proper Use

5000 Series Cup Shape Respirator (AS NZS)

Please review the instruction leaflet provided with the product, prior to use. Also refer to ASNZS 1715 Selection, Use and Maintenance of Respiratory Devices.

Technical Support

Australia/New Zealand

Ph Aus: 1300 139 166 Ph NZ: 0800 322 200

Email: hlshspamarketing@Honeywell.com

RELATED PRODUCTS

© Honeywell International Inc.