

TECHNICAL DATA

Fluke Networks MicroScanner™ 2 Industrial Ethernet Cable Verifier



Key features

- Graphical wire map, length, cable ID, and distance to fault
- Test RJ11, RJ45, Coax, and Industrial Ethernet connector types
- Locate cables with IntelliTone™ digital and analog toning
- Verify 10/100/1000 Ethernet and detects PoE
- Work in any environment with backlit LCD screen

Product overview: Fluke Networks MicroScanner™ 2 Industrial Ethernet Cable Verifier

The Fluke Networks MicroScanner™ 2 Industrial Ethernet Cable Verifier performs continuity tests on RJ45, M12X, M12D, and M8D terminated cables in seconds and displays results graphically so you can see opens, shorts, and crossed wires.

It also reports which end of the cable has a problem and reports the distance to an open connection within the cable. Cable failures result in costly production downtime so it's important to quickly identify where the cable is broken so it can be replaced or repaired.

Includes Duffle Bag, Multi-Connector Adapter, Cat6A patch cord, RJ45 male to RJ45 female patch cord , RJ45/M12X patch cord, RJ45/M12D patch cord, RJ45/M8D patch cord for testing of M12X, M12D, M8D terminated cables.

Specifications: Fluke Networks MicroScanner™ 2 Industrial Ethernet Cable Verifier

Ordering information



MS2-100-IE

MS2-100-IE Cable Verifier

Includes:

- MicroScanner™ 2 Industrial Ethernet Basic Kit with Duffle Bag
- Multi-Connector Adapter
- Cat6A patch cord
- RJ45 male to RJ45 female patch cord
- RJ45/M12X patch cord
- RJ45/M12D patch cord
- RJ45/M8D patch cord for testing of M12X
- M12D
- M8D terminated cables

Fluke. *Keeping your world up and running.®*

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853

In Canada (800) 36-FLUKE

From other countries +1 (425) 446-5500

www.fluke.com

©2025 Fluke Corporation.

Specifications subject to change without notice.
06/2025

**Modification of this document is not permitted
without written permission from Fluke
Corporation.**